

CPCI Backplane Manual

PRODUCT DOCUMENTATION

PD12 CP6-BP8-P47-STD-SL

Reference ID: 24229 PD12

Revision: 01

Issued: March 01, 2002



The product described in this manual is in compliance with all applied CE standards.



Revision History

| Manual/Product Title: | | CPCI Backplane Manual: Product Documentation: CP6-BP8-P47-STD-SL | |
|-----------------------|------------------------------|--|---------------|
| Reference ID: | | 24229 PD12 | |
| Rev. Index | Brief Description of Changes | | Date of Issue |
| 01 | Initial Issue | | Mar. 01, 2002 |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Imprint

Copyright © 2002 PEP Modular Computers GmbH. All rights reserved. This manual may not be copied, photocopied, reproduced, translated or converted to any electronic or machine-readable form in whole or in part without prior written approval of PEP Modular Computers GmbH.



DISCLAIMER:

PEP Modular Computers GmbH rejects any liability for the correctness and completeness of this manual as well as its suitability for any particular purpose.

This manual was realized by: **TPD/Engineering, PEP Modular Computers GmbH.**



1. Introduction

The specific product description provided with this product documentation is part of the PEP’s CPCI Backplane manual. For further information, in particular regarding general details as well as safety and warranty statements, refer to the CPCI Backplane Manual, ID 24229.

2. CP6-BP8-P47-STD-SL Positronic Type Backplane

The main features of the 6U, 8-slot, Positronic type system slot left backplane CP6-BP8-P47-STD-SL are described in the following table:

Table 1: Distinctive Features of Backplane CP6-BP8-P47-STD-SL

| Feature | Specification |
|---------------------------|---|
| Form Factor | 6U |
| Size | 202.2*262.05 mm |
| Number of Slots | 8 (System slot is on the left side of this backplane) |
| Bus Resolution | 64 bits |
| Bus Frequency | 33MHz |
| Rear I/O Connectivity | P3 to P5 on all slots |
| Hot-Swap Capability | Yes |
| Power Supply Connectors | Positronic PCIH47, 47-contact (Power supply connectors are on the right side of this backplane.) |
| Redundant Power Supply | Yes |
| System Management | Yes |
| Flexible Grounding Option | Yes |
| Fan Connector | Yes |
| MSD Connector | Yes |
| Power LED | Yes |
| PS-ON Connector | Yes |
| Reset Function Connector | Yes |



3. Board Layout

Figure 1: CP6-BP8-P47-STD-SL Board Layout (Front)







Figure 2: CP6-BP8-P47-STD-SL Board Layout (Reverse)





4. Signalling Environment

4.1 V(I/O) Setting

There is one block of three high-current terminals (designated as V(I/O)) for connecting V(I/O) to either the +5V or +3.3V power supply. V(I/O) must be connected either to the +5V or the +3.3V input power. It is the responsibility of the system integrator to ensure that the required signalling voltage is implemented and that the backplane P1 connector coding corresponds to the implemented signalling voltage.



Warning!

Using both 3.3V and 5V boards within the same backplane segment may result in damage to your equipment. Please note that the presence of only one 5V board determines a 5V signalling environment. The default setting is 5V.

4.2 P1 Connector Coding for V(I/O)

The CompactPCI Specification foresees coding of the P1 connector to correspond to the signalling environment of the PCI bus. For this reason, only boards with universal or the corresponding coding can be physically inserted into the backplane. PEP's factory default setting for V(I/O) is +5V and male, 1567 code, brilliant blue coding keys are used.



Warning!

Using boards with an inadequate signalling voltage may result in damage to your equipment. Therefore, when changing the signalling environment from 5V to 3.3V or vice versa, it is mandatory that proper coding keys are used (refer to chapter 3 of the CPCI Backplane Manual, ID 24229, for details).

5. Interfaces

5.1 Power

This backplane is designed to accommodate several different schemes for power input. Pluggable 3U and 6U power supplies can be used as well as non-pluggable power supplies. In addition it is possible to extend the backplane's power busses for adding additional power supplies. Appropriate provisions have been made on both the left side as well as the right side of the backplane for power bus extension

5.1.1 Terminal Type Power Input

Both bolt type terminals and Faston/M4 type terminals can be provided for inputting DC power to this backplane. These terminals are primarily designed for extending the DC power busses, but they can also be used with non-pluggable power supplies for providing primary DC power input. Refer to Figure 2 for terminal locations.




5.1.2 Pluggable Power Supply and Line Input

The V1 ... V4 output voltages from the power supply unit to the backplane are connected via a 47-contact, female, Positronic type power supply connector.

The main power supply input power is connected directly to pins 45, 46, and 47 of the power supply connector. The is accomplished by means of a single, closed barrel pass-through contact for each pin via the reverse side of the backplane.

Figure 3: Orientation and Pinouts of CP6-BP8-P47-STD-SL Positronic 47-pin Connector



**Table 3: Positronic 47-Pin Connector Pinout**

| PIN | SIGNAL NAME | DESCRIPTION | PIN | SIGNAL NAME | DESCRIPTION |
|---------|-------------|-------------------|-----|--------------|------------------------------|
| 1 - 4 | V1 | V1 OUTPUT (+5V) | 32 | V2ADJ | V2 ADJUST |
| 5 - 12 | RTN | V1 and V2 RETURN | 33 | V2 SENSE | V2 REMOTE SENSE |
| 13 - 18 | V2 | V2 OUTPUT (+3.3V) | 34 | S RTN | SENSE RETURN |
| 19 | RTN | V3 RETURN | 35 | V1 SHARE | V1 CURRENT SHARE |
| 20 | V3 | V3 OUTPUT (+12V) | 36 | V3 SENSE | V3 REMOTE SENSE |
| 21 | V4 | V4 OUTPUT (-12V) | 37 | IMPB_SCL | IMPB SYS CLOCK |
| 22 | RTN | SIGNAL RETURN | 38 | DEG# | DEGRADE SIGNAL |
| 23 | RESERVED | RESERVED | 39 | INH# | INHIBIT |
| 24 | RTN | V4 RETURN | 40 | IMPB_SDA | IMPB SYS DATA |
| 25 | GA0 | GA BIT 0 | 41 | V2 SHARE | V2 CURRENT SHARE |
| 26 | RESERVED | RESERVED | 42 | FAL# | FAIL SIGNAL |
| 27 | EN# | ENABLE | 43 | IMPB_PWR | IMPB POWER |
| 28 | GA1 | GA BIT 1 | 44 | V3 SHARE | V3 CURRENT SHARE |
| 29 | NC | NOT CONNECTED | 45 | CGND | CHASSIS GROUND |
| 30 | V1SENSE | V1 REMOTE SENSE | 46 | ACN / +DC IN | AC INPUT NEUTRAL / +DC INPUT |
| 31 | GA2 | GA BIT 2 | 47 | ACL / -DC IN | AC INPUT LINE / +DC INPUT |




5.2 Fan Connectors

The backplane is equipped with four connectors for supplying power for fan(s) and for connecting a fan speed control device. JP21/23 (FAN1/2), are 3-contact male connectors which supply +12V for fan operation as well as the possibility to connect to a speed control device for regulating air flow within the system sub-rack. JP22/24 (NTC1/2), are 2-contact male connectors which provide a separate connection for a speed control device and are designed to be used in conjunction with JP21/23.

For fans that have their own speed control or where no control is required, pins 1 and 2 of JP21/23 can be used. For external speed control of fans, pins 2 and 3 of JP21/23 and pins 1 and 2 of JP22/24 are used. Pin 3 of JP21/23 and pin 2 of JP22/24 are connected internally on the board side to each other.

External air flow regulation can be accomplished using a negative thermal coefficient (NTC) device connected to JP22/24

Figure 4: Orientation and Pinouts of CP6-BP8-P47-STD-SL Connectors JP21/23 and JP22/24






5.5 System Monitor and Control Connectors JP11 and JP12

This backplane is provided with two connectors for system monitor and control signal interfacing to external devices. Both are 26-contact, male, double pin-row connectors, and have the same signal pinout configuration. The system management bus (IPMB0), the power supply monitor and control signals, and push button reset (PRST#) signal are all implemented on these connectors.

Figure 7: Orientation and Pinout of the CP6-BP8-P47-STD-SL SMC Connectors JP11 and JP12






5.6 MSD Connectors

Two 4-pole Molex female connectors, JP3 and JP4, are equipped on the backplane for the connection of mass storage devices (drives) to the +5V/+12V power supply of the bus.

Figure 8: Orientation and Pinouts of CP6-BP8-P47-STD-SL Connectors JP3 and JP4

| | | | |
|---|---|--|-----------------|
|  | | Table 9: Pinouts of CP6-BP8-P47-STD-SL Connectors JP3 and JP4 | |
| | | Pin | Function |
| | 1 | 1 | +12V |
| | 2 | 2 | GND |
| | 3 | 3 | GND |
| | 4 | 4 | +5V |